

INSTALLATION INSTRUCTIONS

TRANSFORMER KIT AXWR020TA

For use with FOSSIL FUEL KIT AXWR02FFA1

These instructions must be read and understood completely before attempting installation.

Introduction

The transformer is designed and recommended for use with the Fossil Fuel Kit (AXWR02FFA1) when the input voltage is lower than 104-110V. The transformer is used to replace the 40VA transformer provided with the Furnace.

Installation of Transformer

⚠ WARNING

Electrical shock hazard.

Turn OFF electric power at fuse box or service panel before making any electrical connections.

Failure to do so can result in death, property damage and/or personal injury.

1. Turn off all power to the furnace at the fuse box.
2. Remove transformer from furnace control box (Make note of the wire colors and locations of connections to circuit board).
3. Place new transformer in same area as removed transformer, see picture.
4. Use provided self tapping screws to attach the transformer to the control box.
5. Wire the transformer leads, using the same colors and connection points noted in **STEP 2**.

